

# How to Guide to reduce wind driven rain water ingress entering through W

[www.jcu.edu.au/cyclone-testingstation](http://www.jcu.edu.au/cyclone-testingstation)

---

## LIMITATIONS OF THE GUIDE

---

The Cyclone Testing Station (CTS) has taken all reasonable steps and due care to ensure that the information contained herein is correct at the time of publication. CTS expressly exclude all liability

## Step 2

Ensure the indoor side of the window frames are clean, dry and free of dust, grease or any other contaminants.

## Step 3

Pre-cut the plastic film to approximately 400 mm in height

## Step 4

